

# ANILOX ROLL BRUSHES



**Stainless Steel** Anilox roll brush for use on **ceramic anilox rolls**.  
Available with hair thickness of 0,10 and 0,08mm.



**Phosphorbronze** Anilox roll brush for use on **chrome plated anilox rolls**.  
Available with hair thickness of 0,10 mm.



Nylon brush for use on cliché plates and for ceramic and chrome plated anilox rolls > 360 L/cm

**Note: Always use an appropriate cleaning agent in combination with any of these brushes! Dry use may cause scratches!!!**